

XLERATOR NOZZLE REPLACEMENT

Caution:
Disconnect Power Supply to Dryer
before servicing dryer.

- 1) Remove cover by removing the 2 tamper proof screws on the side of the cover. If the cover has a green ground wire attached unplug it at the cover.
- 2) Remove the old nozzle by removing the 3 screws holding it in place. Save screws for reuse.
- 3) Install the replacement nozzle using the saved screws. Do not over tighten the screws.
- 4) Reinstall the cover by first reconnecting the ground wire if supplied.